For product support please call: 1300 369 193

BM5100-BEAR

Video Monitor



Ma vtech * vtech User's manual


0

CONGRATULATIONS

on purchasing your new VTech product. Before using this product, please read Important safety instruction

This manual has all the feature operations and troubleshooting necessary to install and operate your new VTech product. Please review this manual thoroughly to ensure proper installation and operation of this innovative and feature-rich VTech product.

WHAT'S IN THE BOX



Specifications are subject to change without notice.



IMPORTANT SAFETY INSTRUCTIONS

When using your equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

- 1. Follow all warnings and instructions marked on the product.
- 2. Adult setup is required.
- 3. This product is intended as an aid. It is not a substitute for responsible and proper adult supervision and should not be used as such. 4. This product is not intended for use as a medical monitor
- 5. Do not use this product near water. For example, do not use it next to a bath tub, wash bowl, kitchen sink, laundry tub or
- swimming pool, or in a wet basement or shower. 6. CAUTION: Use only the batteries indicated in this manual. There may be a risk of explosion if a wrong type of battery is used for the
- parent unit. Use only the supplied rechargeable battery or the parent unit. Do not dispose of batteries in a fire. They may explode. 7. Use only the adaptors included with this product. Incorrect adaptor polarity or voltage can seriously damage the product. Baby unit power adaptor: Output: 5V DC 1000mA: Parent unit power adaptor: Output: 5V DC 1000mA.
- 8. The power adaptors are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet
- 9. For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible. 10. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 11. Unplug the power cords before replacing batteries. 12. Do not cut off the power adaptors to replace them with other plugs, as this causes a hazardous situation.
- 13. Do not allow anything to rest on the power cords. Do not install this product where the cords may be walked on or crimped. 14. This product should be operated only from the type of power source indicated on the marking label. If you are not sure
- of the type of power supply in your home, consult your dealer or local power company. 15. Do not overload wall outlets or use an extension cord.
- 16. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
- 17. This product should not be placed in any area where proper ventilation is not provided. Slots and openings in the back or bottom of this product are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register.
- 18. Never push objects of any kind into this product through the slots because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.
- 19. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the product other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.
- 20. You should test the sound reception every time you turn on the units or move one of the components.
- Periodically examine all components for damage.
- 22. Be aware of possible loss of privacy while using public airwaves. Conversations may be picked up by other nursery monitors, cordless phones, scanners, etc.
- 23. Children should be supervised to ensure that they do not play with the product.
- 24. The product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SAVE THESE INSTRUCTIONS

- Cautions
- 1. Use and store the product at a temperature between 0°C and 40°C
- Do not expose the product to extreme cold, heat or direct sunlight. Do not put the product close to a heating source. Batteries should not be exposed to excessive heat such as bright sunshine or fire.
- 4. Make sure the baby unit(s) and the adaptor cord(s) are always out of reach of the baby, at least 1 metre away from
- the baby or cot, to avoid a possible strangulation hazard. 5. Never place the baby unit(s) inside the baby's cot or playpen. Never cover the baby unit(s) or parent unit with anything such as a towel or a blanket.
- 6. Other electronic products may cause interference with your baby monitor. Try installing your baby monitor as far away from these electronic devices as possible: wireless routers, radios, cellular telephones, intercoms, room monitors, televisions, personal computers, kitchen appliances and cordless telephones.

USING THE BABY MONITOR (CON'T)

Zoom

- You can zoom in while viewing images from the baby unit a
- Press again to zoom out.

Talk

You can use the TALK function of the parent unit to comfort your baby in Single CAM and Patrol

- 1. Press and hold TALK on the parent unit. The TALK light turns on.
- 2. Speak towards the microphone on the parent unit. Your voice is broadcast to the baby unit.
- 3. Release TALK to stop the broadcast. The TALK light goes off. The speaker is then turned on for around 20 seconds, so you can hear your baby.

NOTE

 The parent unit speaker is muted during voice broadcast. Sound transmission from the baby unit resumes after TALK is released.

Lullaby

The baby monitor has five lullables and four soothing sounds for you to comfort your baby. You can play the lullabies or soothing sounds on the baby unit using the parent unit.

To play lullaby using the parent unit:

- 1. Press MENU when the parent unit is idle.
- 2. Press V or A to choose Lullaby, then press SELECT.
- 3. Press ∨ or ∧ to choose 🎊 Play Melodies, then press SELECT.
- 4. Press \checkmark or \land to choose a lullaby, then press **SELECT**.

To play soothing sound using the parent unit:

- 1. Press **MENU** when the parent unit is idle.
- 2. Press ∨ or ∧ to choose to choose to choose 2. Press ∨ or ∧ to choose 2. Press V or ∧ to choo
- 3. Press \checkmark or \land to choose $\overset{\frown}{\overset{\frown}{\overset{\frown}{\overset{\frown}{\overset{\bullet}}}}$ Play Soothing Sounds, then press SELECT.
- 4. Press ∨ or ∧ to choose a soothing sound, then press SELECT.
- The lullaby playback on the baby unit will be paused when receiving talkback from the parent unit.
- To stop playing lullaby or soothing sound:
- 1. Press MENU when the parent unit is idle.
- 2. Press ∨ or ∧ to choose to choose to choose 2. Press ∨ or ∧ to choose 2. Press ∨ ot choose 2. Press ∨
- 3. Press \vee or \wedge to choose **(I)** Stop, then press SELECT.

To set auto timer for lullaby:

While the baby unit is playing lullaby or soothing sound, the auto timer feature helps you



Sensitivity Level Highest

Mediun

High

Low

Lowes










CONNECT AND CHARGE THE BATTERY

Install the parent unit battery

The parent unit runs on rechargeable battery or AC power. To continuously monitor your baby, keep the parent unit connected to AC power. With the battery alone, the parent unit can cordlessly run for approximately 2.5 hours.

Use only the battery supplied with this product. If the parent unit will not be used for a long time, disconnect and remove the battery to prevent possible leakage






To replace the battery, press down on the battery compartment cover and pull it out, then follow the steps above to install the battery.

Connect the baby monitor

Use only the power adapters supplied with this product.

Make sure the baby monitor is not connected to a switch controlled electric outlet. Connect the power adapters in a vertical or floor mount position only. The adapters' prongs are not designed to hold the weight of baby monitor, so do not connect them to any ceiling, under-the-table, or cabinet outlets. Otherwise, the adapters may not properly connect to the outlets. Make sure the parent unit, the baby unit and the power adapter cords are out of reach of children.



Charge the parent unit battery

When you have connected the parent unit and installed its battery for the first time or after power outage, the parent unit powers on automatically. The battery icon indicates the battery status (see the following table).

- The parent unit battery is fully charged after 3 hours of continuous charging.
- It takes longer to charge the battery when the parent unit is turned on. To shorten the charging time, turn the parent unit off while charging. The standby time varies depending on the sensitivity level you set, your actual use and the age of the battery.
- The battery icon is off and No battery is installed but Install the parent unit battery. displays. operates using AC power, Charge without interruption (at least 30 minutes). or the battery has been installed incorrectly The screen displays Battery The battery has very little Charge without interruption (about charge and may be used low at Parent Unit and . 30 minutes) for only a short time. The 🛲 light flashes The battery icon becomes The battery is fully charged. To keep the battery charged, connect it to AC power when not in use. solid III.

2 BEFORE USE

NOTE 1



This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should not be used as such

Test your baby monitor

You may test the baby monitor before initial use, and at regular times thereafter. **OCAUTION**

- For hearing protection, make sure the parent unit is more than 1 metre away from the baby unit(s). If you hear any high-pitched noise, move the parent unit further until the noise stops. You can also press $VOL \oplus$ on the parent unit to reduce the noise.
- . Make sure your baby unit and parent unit are on. 2. The parent unit displays images from the baby unit. • Speak towards the microphone of the baby unit.
- You will hear the sound at the parent unit.
- 3. If you have two baby units, press VIEW on your parent
- unit. The screen switches to the other baby unit. Then, repeat step 2

NOTE 🗄

When the parent unit displays \mathbb{Z} and then \mathcal{R} No Link to CAM # (# represents the baby unit number) and the LINK LED light flashes, move the parent unit closer to the baby unit (observe the minimum distance of 1 metre).

🔆 TIP

Increase the speaker volume of the parent unit if you cannot hear the sounds transmitted from the baby units.

Positioning the baby monitor

() CAUTION Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's crib or playpen.


NOTE





- 1. Place the baby unit more than 1 metre away from your baby.
- 2. Place the parent unit more than 1 metre away from the baby unit(s) to avoid screeching





Operating range

USING THE BABY MONITOR

Power on or off the baby unit

132

Turn on or off the parent unit screen

- hear sound from the baby unit.

Adjust the speaker volume

For parent unit:

For baby unit:

Press **VOL** ▼ / **VOL** ▲ to adjust the listening volume. The baby unit speaker volume determines the lullaby volume and talkback volume transmitted from parent unit. Level 1 is the softest while Level 5 is the loudest.

- selection.

Adjust LCD brightness

You can change the brightness of the parent unit screen from Level 1 to Level 5. The LCD brightness is preset to **Level 3**.

- 1. Press **MENU** when the parent unit is idle.
- selection.

Temperature format

🖹 Note

Single CAM

In Split mode:

NOTE

Patrol

Split

- automatically stop the lullaby or soothing sound after playing for 15/30/45/60 minutes. You can set auto timer for lullaby with the parent unit. 1. Press **MENU** when the parent unit is idle.
- 2. Press ∨ or ∧ to choose 🛺 Lullaby, then press SELECT.
- 3. Press ∨ or ∧ to choose 🕑 Auto Timer, then press SELECT.
- 4. Press ∨ or ∧ to choose the desired lullabies duration, then press SELECT.
- After 15/30/45/60 minutes, the lullaby or soothing sound will stop automatically.

Set sleep timer (Sound activation)

You can set the auto screen-off timer so that the LCD will turn off automatically when the parent unit does not detect sound for the period of time you set (1, 2 or 3 minutes). 1. Press **MENU** when the parent unit is idle.


2. Press ∨ or ∧ to choose Sleep timer, then press SELECT.

3. Press \vee or \wedge to choose the desired idle time for the LCD to turn off automatically, or choose \approx Off, then press SELECT.

- After 1/2/3 minutes, the parent unit screen will turn off automatically. If you have chosen
- **Off**, there will no sleep timer set. The parent unit screen will turn on when sound is detected coming from the baby unit. The level of noise to enable the screen to be sound activated depends on the sound sensitivity level set (see below).

Adjust the sound sensitivity of the baby unit

You can choose to hear sounds from the baby unit all the time, or to hear sounds that exceed a certain level. You can use the parent unit to adjust the microphone sensitivity of your baby unit from Lowest to Highest. The higher the sensitivity level, the more sensitive the baby unit is in detecting sounds for transmitting to the parent unit. The VOX sound sensitivity level is preset to Highest.



- 1. Press **MENU** when the parent unit is idle.
- 2. Press ∨ or ∧ to choose Select.
- 3. Press ∨ or ∧ to choose the desired sensitivity level, then press SELECT to confirm your selection. 尝TIP
- You can adjust the baby unit placement to improve the sound detection.

Set alert tone

No link alert

You can set the parent unit to beep when the link between the parent unit and the baby unit is lost. 1. Press **MENU** when the parent unit is idle.

- 2. Press ∨ or ∧ to choose (Alert Tone, then press SELECT.
- 3. Press ∨ or ∧ to choose *P* No Link Alert, then press SELECT.
- 4. Press ∨ or ∧ to choose On or Off, then press SELECT to confirm your selection.

Low battery tone

You can set the parent unit to beep when the parent unit operates in low battery condition.

- 1. Press **MENU** when the parent unit is idle.
- 2. Press **v** or **A** to choose **O** Alert Tone, then press **SELECT** to select.
- 3. Press **SELECT** again to choose
- Low Battery Tone

4. Press ∨ or ∧ to choose On or Off, then press SELECT to confirm your selection.

The maximum temperature can be set between 21 °C (70 °F) and 30 °C (86 °F).

3. Press V or A to choose Minimum or Maximum, then press SELECT.

2. Press ∨ or ∧ to choose U Temperature, then press SELECT.

Monitor the temperature

between 11 °C (52 °F) and 20 °C (69 °F).

detected temperature is out of range.

1. Press **MENU** when the parent unit is idle.

1. Press **MENU** when the parent unit is idle.

Your baby unit monitors the temperature of your baby's room with its built-in temperature sensor. If the detected temperature is outside of the preset temperature range, the parent unit will display alert message.

You can set the desired room temperature alert range. The minimum temperature can be set

4. Press **V** or **A** to choose the desired minimum or maximum temperature, then press **SELECT** to

You can turn on the temperature alert tone so that the parent unit will emit an alert tone if the

Set temperature range

confirm your selection.

Temperature alert tone

The operating range of the baby monitor is up to 300 metres outdoors or 50 metres indoors. The actual operating range may vary depending on the environmental conditions and other interferences such as walls, doors and other obstructions.

Slide the **ON/OFF** switch to **ON** to turn on the baby unit. The **ON/OFF** LED light turns on. • Slide the ON/OFF switch to OFF to turn off the baby unit. The ON/OFF LED light turns off.

Power on or off the parent unit

• Press and hold **POWER** to turn on the parent unit. The screen turns on. Press and hold **POWER** to turn off the parent unit. The screen turns off.

You can turn on or off the parent unit screen without powering off the parent unit. You can still

Press and hold **LCD ON/OFF** on the parent unit to turn off the screen.

Press any key on the parent unit to turn on the screen again.

Press DV0L / V0L On the parent unit at any time when viewing images.

1. Press **MENU** when the parent unit is idle.

2. Press \checkmark or \land to choose \bigotimes Camera, then press SELECT.

3. Press ∨ or ∧ to choose 😢 Volume on Camera, then press SELECT.

4. Press V or A to choose the desired volume level, then press SELECT to confirm your

2. Press \checkmark or \land to choose \bigcirc Brightness, then press SELECT.

3. Press V or A to choose the desired level of brightness, then press SELECT to confirm your

2. Press 🗸 or 🔺 to choose 🐻 Temperature, then press SELECT. 3. Press ∨ or ∧ to choose Set alert, then press SELECT.

4. Press ∨ or ∧ to choose On or Off, then press SELECT to confirm your selection.

You can choose to display the temperature in Fahrenheit (°F) or Celsius (°C).

1. Press MENU when the parent unit is idle.

2. Press ∨ or ∧ to choose ¹ Temperature, then press SELECT.

3. Press ∨ or ∧ to choose ^{*}F^{*}C Format, then press SELECT.

4. Press ∨ or ∧ to choose °F or °C, then press SELECT to confirm your selection.

Turn on or off the vibration

You can turn on the vibration feature so that the parent unit vibrates when it receives any of No link alert or Temperature alert tone after turning on the respective alert tones. 1. Press MENU when the parent unit is idle.

2. Press V or A to choose **Vibration**, then press **SELECT**

3. Press ∨ or ∧ to choose Con or Con

4. Press **SELECT** to confirm your selection.

 If the vibration feature is turned on, the parent unit may vibrate as it receives sound broadcast from the baby unit. The vibration alert for sound detection will only vibrate approximately every 20-30 seconds.

Monitoring mode * for pairing with BM5110-BEAR only

Every time the parent unit is turned on, it displays a baby unit in **Single CAM** mode. If there are two baby units in your system, you can also monitor your baby in Patrol or Split mode.

The screen displays image of a single baby unit in full screen.

A single cam view that transitions to a different baby unit every 10 seconds.

The screen displays all baby units.

You can choose the desired monitoring mode.

1. Press **MENU** when the parent unit is idle.

2. Press **v** or **A** to choose **Monitoring Mode**, then press **SELECT**. 3. Press v or A to choose Single CAM, Patrol or Split, then press SELECT.

In Single CAM or Patrol mode:

• Press **VIEW** to view the next baby unit.

• Press \wedge , \vee , \triangleleft or > to select a baby unit. • Press 🕀 or **VIEW** to view the selected baby unit temporarily in **Single CAM** mode. It returns to **Split** mode after 10 seconds.



• The parent unit is muted while in **Split** mode.

NIGHT VISION


The baby unit has infrared LEDs that allow you to see your baby clearly at night or in a dark room. When the baby unit being viewed detects low light levels, the infrared LEDs are switched on automatically. The images from the baby unit are in black and white, and \checkmark appears on the screen.

NOTES

- It is normal if you see a short white glare on your parent unit screen as the baby unit is adapting
- to the dark environme When the infrared LEDs are on, the images are in black and white. This is normal.

Depending on the surroundings and other interfering factors, like lightings, objects, colors and backgrounds, the video quality may vary. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry display.

BABY UNIT OVERVIEW




- 5 ▼/**VOL/**▲
- Press to adjust the baby unit speaker volume. It determines the lullaby volume and talkback volume transmitted from the parent unit
- 6 ►/■ Play/Stop
- Press to play or stop lullabies on the baby unit.
- unit when a desired baby unit slot is chosen at the parent unit.
- 13 **Threaded socket**
- · For wall mount installation use. 14 Power jack

(3

(4)

PARENT UNIT OVERVIEW




LED lights Indicate the different statuses of the parent unit. For details, refer to Parent

- unit liahts.
- 2 LCD display VOL 🗘 3
- 4 **VOL**
- ⊕ Zoom
- Press to zoom in or out.
- 6 VIEW / LCD ON/OFF
- Microphone
- 8 POWER
- 9 TALK
- Press and hold to talk to the selected baby unit.
- 10 <

upward.

- While in a menu, press to return to the main menu or idle screen. While viewing zoomed image, press and hold to move the zoomed image
- · While in Split mode, press to move the selection box leftward.
- 11 👗 • While in a menu, press to scroll up. While viewing zoomed image, press and hold to move the zoomed image




- While in a menu, press to choose an
- While viewing zoomed image, press and hold to move the zoomed image rightward.
- While in **Split** mode, press to move the selection box rightward.

13 MENU/SELECT

- Press to enter the menu • While in a menu, press to choose an
- item, or save a setting.
- 14 **V**
- · While in a menu, press to scroll down. • While viewing zoomed image, press and hold to move the zoomed image downward
- 15 Antenna
- 16 Stand
- 17 Speaker
- 18 Power jack
- 19 Battery compartment cover

MOUNT THE BABY UNIT (OPTIONAL)



 Check for reception strength and camera angle before drilling the holes.


Place the wall mount bracket on a wall and then use a pencil to mark the top and the bottom holes as shown. Remove the wall mount bracket and dril two holes in the wall (7/32 inch drill bit).



If you drill the holes into a stud, go to step 3.

-OR-

If you drill the holes into an object other than a stud, insert the wall anchors into the holes. Tap gently on the ends with a hammer until the wall anchors are flush with the wall.




Align the wall mount bracket and screws with the holes in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket position is fixed. You can tighten the other screw in the top hole.



bracket. Tighten the screw into the threaded socket at the bottom to secure the baby unit.

> You can maximize your baby unit's viewing angles by tilting the wall mount bracket.

Hold the baby unit, and then rotate the knob in anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in clockwise direction to tighten the joint and secure the angle.



Insert the screws into the holes and tighten the screws until only 1/4 inch of the screws are exposed.



Place the baby unit on the wall mount bracket. Tighten the screw into the threaded socket at the bottom to secure the baby unit. Align the holes on the wall mount bracket with the screws on the wall, and slide the wall mount bracket down until it locks into place

STORAGE adapters in a cool and dry place.

^Q_{∞∆} Frequently asked questions

Try the following (in the order listed) for common cure: Why does the baby monitor not 1. Disconnect the power to the baby units and the parent unit

	 Remove the batteries in the part Wait a few seconds before conner Turn on the baby units and the p Wait for the parent unit to synch 	
Why don't the power-on light of the baby unit and	Perhaps the parent unit is not conr Then, <u>press and hold</u> POWER to su	
parent unit go on when I switch on the units?	Perhaps the baby unit is not conne slide the ON/OFF switch to ON to	
Why doesn't my parent unit charge	Make sure the power is not contro	
while connected to AC power?	Make sure the battery is correctly i	
	You may have used the battery for	
Why is my screen in black and white?	The screen is in black and white du	
Why do I get glare or blurry display on my screen when viewing my baby at night?	During night-time or in a dark roon the image quality on your parent un display.	
Why does the baby monitor produce a high-pitched noise?	The parent unit and baby units may • Move the parent unit away from • Turn down the volume of your p	
Why does the parent unit beep?	The baby units may be out of rang	
	The parent unit may not have enou	
	If your parent unit is in Split mode,	
	The temperature of your baby's ro	
Why does the parent unit beep/ vibrate frequently in Split mode?	You may have set the VOX sensitive of all sounds including background	
Why does the parent unit react too quickly to other sounds?	The baby unit also picks up other s speaker volume.	
Why don't I hear a sound/Why can't I	The parent unit speaker volume ma	
hear my baby cry?	You may have set a low VOX sensit	
Why can't I establish a connection?	The baby units may be out of rang	
Why is the connection lost every		

Why is the connection lost even now and then? Why are there sound interruptions?

these devices as pos to the baby unit you have powered on

To keep this product working well and looking good, follow these guidelines: • DO NOT expose it to direct sunlight or moisture. Avoid dropping the product or treating it roughly. Clean with a soft cloth


• Make sure the baby unit and parent unit are dry before you connect them to the mains again.

Seneral product care

Below are the questions most frequently asked about the baby monitor

• DO NOT immerse the parent unit and the baby unit in water and do not clean them under the tap. • DO NOT use cleaning spray or liquid cleaners.

PARENT UNIT LIGHTS



Sub

· Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).

When you are not going to use the baby monitor for some time, remove the rechargeable battery from the parent unit. Store the parent unit, the baby unit and the

rent unit. Then, install the batteries again

- ecting power back to the baby units and the parent unit parent uni
- pronize with the baby units. Allow up to one minute for this to take place.
- nected to the power. Insert the appliance plug into the parent unit and put the adapter in a wall socket. switch on the parent unit and to establish connection with the baby unit.
- ected to the power. Insert the appliance plug into the baby unit and put the adapter in a wall socket. Then, switch on the baby unit and to establish connection with the parent unit.
- lled by a wall switch.
- nstalled in your parent unit r a long time. Replace a new battery.
- ring night-time or in a dark room when the night vision feature is activated. This is normal. m, the surroundings and other interfering factors, like lightings, objects, colors and backgrounds may affect unit screen. Adjust the baby unit's angle or place the baby unit at a higher level to prevent glare and blurry

y be too close to each other. the baby units until the noise stops; OR parent unit.

- ge. Move the parent unit closer to the baby units (but not less than 1 metre).
- ugh charge for the parent unit to perform normally. Charge the battery in the parent unit for up to 3 hours.
- , some of your baby units may detect sounds.
- oom may be too high or too low. vity level to **Highest** when the sound alert (and vibration) feature is turned on. The parent unit notifies you ad noise with beeps (and vibration). Adjust the VOX sensitivity to a lower level. sounds than those of your baby. Adjust the VOX sensitivity level to a lower level or lower the parent unit
- nay be too low. Press VOL to increase the volume.
- ivity level. See Adjust the sound sensitivity of the baby unit to set to a higher level
- ge. Move the parent unit closer to the baby units (but not less than 1 metre).
- Other electronic and wireless products may cause interference with your baby monitor. Try installing your baby monitor as far away from

If you power on only one baby unit, your parent unit may display 🕱 and 🗞 No link to CAM #, and the LINK LED light flashes. Press VIEW to switch

PARENT UNIT ICONS

Status ic	tatus icons		Main menu icons	
Tul	 Connection status Industry of the strong signal strength is detected between the baby unit and the 	<u>ې</u>	Brightness You can adjust th	
	 parent unit. In or In displays when moderate or low signal strength is detected between the baby unit and the parent unit. Indisplays when the link between the baby unit and the parent unit is lost. 		Sensitivity (VOX With this feature, to hear sounds th microphone sens sensitive the bab	
^]]	LullabyDisplays when the baby unit being viewed is playing lullabies or soothing sounds.	=	Temperature You can turn on t whenever the ro desired tempera	
01	 Current view status Displays the baby unit number of the baby unit that is being viewed. 		You can choose to maximum/minimu	
C	Night visionDisplays when the baby unit being viewed has activated the night vision feature.		Lullaby You can choose a	
-	TalkbackDisplays when you are hold the TALK key on the parent unit.	\mathbf{Q}	Camera You can adjust th talkback volume	
°F ₀r ℃	 Real-time temperature Displays the real-time temperature detected by the baby unit in Fahrenheit (°F) or Celsius (°C) (e.g. 57 °F or 14 °C). 		Vibration You can turn on t Low battery tone turning on the re	
<u>لم</u>	 Temperature alert tone Displays when the temperature alert tone is on. 		Alert Tone settin You can set the p • the parent unit • the link betwe	
\mathbf{i}	Mute alertDisplays when the parent unit is talking to the baby unit.	Z _Z	Sleep timer You can set the a	
{ _ }	Vibration alertDisplays when the vibration is set to on.	_	when the parent 3 minutes). Exit	
	9-level sound indicator		You can select th	
	 III (1 to 3 bars) indicates low sound level detected by the baby unit. IIIIII (4 to 6 bars) indicates moderate sound level detected by the baby unit. IIIIIIII (7 to 9 bars) indicates high sound level detected by the baby unit (e.g. baby crying loudly). 	Warning icons and m		
Ð	Zoom	0-2	The	
-	 Displays when the current image on the parent unit has zoomed in. Battery status 	• !]	The l rech	
)))]	The	
	• 🥅 displays when the battery is low and needs charging.	or	The to desire	
autti	AC power without batteryDisplays when the parent unit is connected to AC power without the battery.	TO	The	

Customer service and product warranty

Please retain this booklet with your sales receipt as proof of the date of purchase.

Customer Service

IMPORTANT

If you require assistance in operating this product, please call the TecHelp Information Line on 1300 369 193 or contact VTech by e-mail at: tcpsupport_au@vtech.com

Voluntary Product Enquiry

In addition to your Statutory Rights and subject to the conditions below, VTech warrants that this product will be free from any defect in materials or workmanship under conditions of normal use for a period of 24 months from date of purchase

VTech does not warrant that the product will be free from defects if defects are caused by an accident, misuse, abuse, improper installation or operation, vermin infestations, lack of reasonable care, unauthorised modification, loss of parts, tampering or attempted repair by a person not authorised by VTech; or where the product has been damaged by lightning or a mains power surge. To make a claim under this Voluntary Product Warranty you must call the TecHelp Information Line on 1300 369 193 or contact VTech by e-mail at: tcpsupport_au@vtech.com where a Customer Service Representative will inform you of the product return process. You will need to ensure that:

- You provide proof of purchase;
- Your product is suitably packaged (original packaging is not required); and You have included all components from the original purchase.

For your records

Date of purchase:

Place of purchase:

Serial number:

For Voluntary Product Warranty purposes, proof of purchase is required so please keep your receipt.

The benefits conferred by this Voluntary Product Warranty are in addition to other rights and remedies that are available to you under law, which cannot be excluded. The processes for this Voluntary Product Warranty in no way limit your rights which arise as a result of your Statutory Rights.

This Voluntary Product Warranty is given by:

VTech Telecommunications (Australia) Pty Ltd ABN 70 136 672 627 Address: 24 Gilby Road, Mount Waverley 3149

IMPORTANT NOTE: THIS IS NOT A PRODUCT RETURN OR SERVICE ADDRESS – PLEASE CONTACT TECHELP BY PHONE OR EMAIL FOR PRODUCT AND WARRANTY SUPPORT. NO LIABILITY WILL BE ACCEPTED BY VTECH FOR PRODUCTS RETURNED TO THIS ADDRESS UNDER THIS VOLUNTARY PRODUCT WARRANTY.

Phone number: 1300 369 193

Email address: tcpsupport_au@vtech.com

Statutory Right

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Disposal of batteries and product

TECHNICAL SPECIFICATIONS

Frequency control Transmit frequency

Channels LCD

Nominal effective range

Power requirements

the LCD brightness.

X setting)

e, you can choose to hear sounds from the baby unit all the time, or hat exceed a certain level. You can use the parent unit to adjust the nsitivity of your baby unit. The higher the sensitivity level, the more by unit is in detecting sounds for transmitting to the parent unit.

the temperature alert tone so that the parent unit beeps oom temperature detected by the baby unit falls outside of the rature range.

e to display the temperature in Fahrenheit (°F) or Celsius (°C), or set the num temperature limit for alerts.

a lullaby or soothing sound to comfort your baby.

the volume of baby unit which determines the lullaby volume and e transmitted from parent unit.

the vibration alert so that the parent unit vibrates when it receives ne, No link alert, Sound alert or Temperature alert tone after respective alert tones.

ing

e parent unit to beep when

nit operates in low battery condition: or veen the parent unit and the baby unit is lost.

auto screen-off timer so that the LCD will turn off automatically It unit does not detect sound for the period of time you set (1, 2 or

this option to exit the menu.

nessages

e selected baby unit is out of range or is turned off.

- battery level of the parent unit is very low and needs to be harged.
- e sound level exceeds the threshold at CAM # in **Split** mode.
- e temperature detected by the baby unit is higher/lower than the sired temperature alert range.

e parent unit is searching for the baby unit.

The crossed-out wheelie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pn) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005. Help protect the environment by disposing of your product or batteries responsibly.

Crystal controlled PLL synthesizer
Baby unit: 2406 - 2475 MHz Parent unit: 2405 - 2475 MHz
32
5" Color LCD (WQVGA 480x272 pixel)
Actual operating range may vary according to environmental conditions at the time of use.
Parent unit: 3.7V Li-polymer battery Baby unit power adapter: Output: 5V DC @ 1A Parent unit power adapter: Output: 5V DC @ 1A