















# Flume Travel System

## Instruction manual



**IMPORTANT:**  
**RETAIN FOR FUTURE REFERENCE**  
**READ CAREFULLY**

# Parts List


<div>A</div> <div></div> <div>pushchair x1</div>	<div>B</div> <div></div> <div>bumper bar x1</div>	<div>C</div> <div></div> <div>rear wheels x2</div>
<div>D</div> <div></div> <div>front wheels x2</div>	<div>E</div> <div></div> <div>rear wheel axle x1</div>	<div>F</div> <div></div> <div>washer x2</div>
<div>G</div> <div></div> <div>plastic eye splice x2</div>	<div>H</div> <div></div> <div>plastic cap x2</div>	<div>I</div> <div></div> <div>round cap x2</div>
<div>J</div> <div></div> <div>raincover x1</div>	<div>K</div> <div></div> <div>car seat x1</div>	

# Assembly


Unpack all contents and check that all parts are present before starting assembly. Please refer to the parts list.

1. Release the pushchair (A) from the locked position by lifting the locking catch from over the locking rivet on the pushchair frame. (Note: You may have to squeeze the legs and handles together first so as to release the tension on the rivet.) Standing behind the pushchair and holding it by the handle, lift the handle upwards to unfold the frame.

**WARNING! Ensure the opened frame is locked in place before you use it.**




2a. Assemble the rear wheels. Place one metal washer (F) onto the end of the rear axle (E). Place one wheel (C) followed by one plastic eye splice (G) and one plastic cap (H). Finally attach the round cap (I) as illustrated. Repeat for the other side.




# Assembly

2b. Fit the assembled rear wheel axle to the pushchair. Insert the ends of the tubing into the housing located on the assembled rear wheel axle. Push upward until you hear it lock and 'click' into position.




3. Attach the front wheels (D). Insert wheel housing onto the front leg and push upward until you hear it 'click' into position. Repeat for other leg.



## Assembly


4. Assemble the bumper bar (B) to the front of the pushchair. Attach the bumper bar connector posts to the frame. Push in the locking clip to secure. Repeat for both sides of the bumper bar.

To remove bumper bar, lift up the locking clip and pull bumper bar away from the pushchair. Ensure both clips are released before trying to remove bumper bar.




## Canopy Adjustment

The canopy can be opened or closed by pulling or pushing on the canopy rim. There is also a viewing window located at the top of the canopy and a pocket at the rear of the canopy.



## Footrest Adjustment

Press on each adjuster in turn while simultaneously pressing down or pulling up lightly on the footrest.




## Brakes

To engage the brake push down the brake locking bar. Lift up bar to release brake.

**WARNING! Always apply the brake when the pushchair is not moving.**

**WARNING! Always apply the brake when you are placing and removing the child.**

**WARNING! Always apply the brake when you are making adjustments to the pushchair.**




## Swivel Wheels

The pushchair has lockable front swivel wheels.

To lock swivel wheels press the pedal down. Repeat on both wheels.

Push up to release and engage swivel wheel.




# Backrest Adjustment

Locate the backrest adjustment mechanism at the rear of the seat. Squeeze the clip on the reclining harness and gently lower the backrest. Alternatively, squeeze the clip on the reclining harness and gently pull up the backrest to the desired height.

**WARNING! Always ensure that the seat is securely fixed in position before use.**

**WARNING! Suitable for newborn babies in the most reclined position only.**


**WARNING! Not suitable for children under 6 months in the most upright position.**




# Harness Operation

A five-point safety harness is provided to restrain your child and should always be worn.

1. To fasten, push the side clips into the centre buckle.




2. Press the side clip prongs and remove from buckle to release the buckle.



3. Sliding adjusters are fitted and should be adjusted to suit your child.

**WARNING! Always adjust the harness to fit your child correctly for their comfort and safety. A loose fitting harness can be very dangerous.**




# Travel System

The car seat (K) can be fitted to the pushchair to create a travel system.

1. Adjust the pushchair backrest to the lowest recline position and fold the canopy.
2. Lower the car seat onto the pushchair ensuring to attach the connectors located both sides of the car seat to the frame. Lift the car seat gently by the handle to check the car seat has locked into place.
3. Refer to the car seat manual and adjust the car seat handle to position C.

**WARNING! Ensure the car seat base aligns with the bumper bar and the car seat connectors are correctly engaged before use.**




# Travel System

1. Refer to the car seat manual and rotate the car seat handle to the carrying position B.
2. Pull out the car seat connector from the pushchair frame to release the connector from the holding pin. Repeat for both sides of the pushchair.
3. Lift the car seat away from the pushchair.

**IMPORTANT:** Refer to the car seat manual for full details of use.


**WARNING! Never attach the car seat forward facing.**

**WARNING! The car seat is compatible with the Babylo Flume Travel System only. DO NOT use car seat with any other model of pushchair.**




# Raincover

1. Place the raincover (J) over the canopy front. Fasten the hook and loop straps around the front legs (a), handle bars (b) and canopy (c) to secure.




2. The raincover also fits in travel system mode (i.e. when the car seat is fitted to the pushchair). Secure with the hook and loop tabs.



# Folding

NOTE. Remove all items from the basket before attempting to fold.  
NOTE. If using with car seat, ensure it has been removed before folding.  
NOTE. Ensure the backrest is in the lowest position before attempting to fold.

1. Lock swivel wheels, fold the canopy and engage the brake.
2. Pull both fold release triggers towards you.
3. Push the handle downwards gently and lower the pushchair to a close.
4. Engage the locking catch.





### **IMPORTANT:** **RETAIN FOR FUTURE REFERENCE** **READ CAREFULLY**

**WARNING! TO AVOID INJURY OR DEATH READ THESE INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP FOR FUTURE REFERENCE.**

**THE CHILD MAY BE HURT IF YOU DO NOT FOLLOW THESE INSTRUCTIONS.**

**WARNING!** Before using, remove and dispose of any plastic bags and other packaging (e.g. fasteners, fixing ties, etc.) and keep them out of reach of children. This product is suitable for one child from birth and up to a maximum weight of 15kg (approx. 3 years).

**Suitable for newborn babies in the most reclined position only.**

**Not suitable for children under 6 months in the most upright position.**

**WARNING!** Never leave the child unattended.

**WARNING!** Ensure all locking devices are engaged before use.

**WARNING!** Follow the manufacturer's instructions.

**WARNING!** Follow suitability recommendations given in the separate car seat instruction manual.

**WARNING!** Always apply the brakes whenever the stroller is stationary.

**WARNING!** Secure the child in the harness at all times.

**WARNING!** Do not carry extra children or bags on this stroller.

**WARNING!** Make sure children are clear of any moving parts if you adjust the stroller. Otherwise they may be injured.

**WARNING!** Do not let your child play with this product.

**Remember, the child's safety is your responsibility:**

- The correct use and maintenance of this stroller are essential.
- Be sure that all clamps and buckles are securely fixed and in place before use.
- When in the stroller, your child must always wear the safety harness, correctly fitted and adjusted, at all times.

- Ensure the parking brake is engaged during the loading and unloading of children.
  - To avoid injury ensure that your child is kept away when unfolding and folding this product.
  - Do not place the product near an open fire or other source of strong heat.
  - Do not allow your child to climb into the stroller.
  - Never leave a raincover, hood or apron on indoors, in a hot atmosphere or near a heat source as your child may overheat.
  - Infant car seats should not be used in place of a cot or cot bed. Should your child need to sleep, it should be placed in a suitable cot or cot bed.
  - Be careful when going up or down kerbs.
  - This product is not suitable for running or skating.
  - Remove your child and fold the stroller when going up or down escalators.
  - If your stroller is used by someone unfamiliar with it e.g. Grandparents, always show them how it works.
  - Do not use this stroller near an open fire or exposed flame.
  - Take care in windy conditions.
  - To prevent damage, always remove the raincover before folding the stroller.
  - Do not place anything on top of the raincover.
  - To prevent your child overheating, always fold or remove a raincover when indoors or in warm environments.
  - The basket for the carriage can carry a maximum load of 2kg with items evenly distributed.
  - The hood pocket can carry a maximum load of 0.5kg.
  - Do not use parts or accessories which are not approved by the manufacturer.
- This product conforms to EN 1888-1:2018+A1:2022**

# Care

---

## Cleaning

- Spot or sponge clean fabrics with mild detergent. Use mild soap or upholstery shampoo. NEVER use bleach. Dry in shade thoroughly before reuse and avoid direct heat and sunlight. Do not iron. Do not dry clean. Do not bleach.
- Wipe clean plastics and metals with a damp cloth.
- Never clean any part of the product with abrasive, ammonia based, bleach based or spirit type cleaners.
- Ensure the product is fully dry before use or storage.
- Always ensure the product is stored in a dry place to prevent mold or mildew developing.

## Maintenance

- The product requires regular maintenance to ensure correct and safe performance.
- Regularly inspect the wheels, locks, brakes, harness, catches, seat adjusters, joints and fixings to ensure they are clean, operating correctly and in full working order.
- Regularly check and lubricate the wheels.
- Do not use this product if any part is broken, torn or missing and use only spares provided by the manufacturer.
- Always check your stroller for loose screws, ensure they are tightened properly.
- If parts become stiff or difficult to operate, ensure dirt is not the cause, then try a light application of a silicon lubricant, ensuring it penetrates between the components. Regular lubrication of moving parts will extend the life of your product and make opening and folding easier.
- After exposure to damp conditions, dry off with a soft cloth and leave fully open in a warm environment. Storing damp will encourage mildew to form.
- Store in a dry place.
- Do not leave in sunlight for prolonged periods as some fabrics may fade.

Due to variation in style and design the illustrations used in this instruction manual are generic.  
Variation in design may occur in the images shown.



Supplied by Baby Factory NZ. Ltd.  
58 Stonedon Drive  
East Tamaki  
Auckland  
New Zealand  
[www.babyfactory.co.nz](http://www.babyfactory.co.nz)